




heat sinks

= 2 =
WT: (KG/M)
R_e: (°C/W/1")


K209 WT:0.15 R_e:30




K166 WT:0.38 R_e:11



K213 WT:0.31 R_e:22




K240 WT:0.61 R_e:12




K111 WT:0.41 R_e:13




K235 WT:0.61 R_e:9




K242 WT:0.4 R_e:15




K112 WT:0.37 R_e:12




K236 WT:0.71 R_e:9.1




K327 WT:0.7 R_e:7.6




K117 WT:0.66 R_e:7.1




k246 WT:0.61 R_e:9.2



K334 WT:0.37 R_e:14



K501 WT:0.65 R_e:8.1



K241 WT:0.64 R_e:9

